



BAR-STYLE WINDOW ARMOR

2019+ DODGE DURANGO

Installation Instructions

475-1417



INCLUDES:

- (1) Driver Side Window Armor
- (1) Passenger Side Window Armor

1. Align Window Armor into position following contour of door frame.
2. Secure Window Armor into place using provided (9) tek screws.

If you have questions or need further assistance please call Technical Support: 1.877.455.6886



209 W. EASY ST., ROGERS, AR 72756 • JOTTOPUBLICSAFETY.COM • 1/25

Jotto Desk™ is a patented product and Registered Trademark of Assembled Products™ Corporation.
Specifications subject to change without notice.

050-0140-00

